


Applies to the following products:

357, 3572SS

Installation Instructions:

1. Trim to length.
2. Install on the active leaf of pair of outswinging doors.
3. Position to cover the meeting stiles gap.
4. Fasten with screws or through bolts provided.

Tools Required:



Gasketing material for fire doors intended for application to listed steel frames and/or classified steel covered composite type, and hollow metal type fire doors rated up to 3 hours; wood and plastic covered composite type fire doors rated up to 1-1/2 hours; and wood core type fire doors rated up to 20 minutes.

(Thresholds may or may not contain gasketing material).

