

# Architectural Door Accessories

**ASSA ABLOY**

## Pemko Door Bottoms

The global leader in  
door opening solutions

Applies to the following door bottom:

**368\_N, 315\_N, 315SSN, 321SSN, 321\_N**

### Installation Instructions:

1. Measure, mark and trim door bottom sweep to full width of the door.
2. Drill pilot holes in door at marks.
3. Mount to door with supplied fasteners.


### Testing/Ratings:

Gasketing material for fire doors intended for application to listed steel frames and/or classified steel covered composite type, and hollow metal type fire doors rated up to 3 hours; wood and plastic covered composite type fire doors rated up to 1-1/2 hours; and wood core type fire doors rated up to 20 minutes.

(Thresholds may or may not contain gasketing material).



### Tools Required:



[www.pemko.com](http://www.pemko.com)

|                 |                 |                  |                 |
|-----------------|-----------------|------------------|-----------------|
| MEMPHIS, TN USA | VENTURA, CA USA | VANCOUVER, BC CA | TORONTO, ON CA  |
| P: 800 824-3018 | P: 800 283-9988 | P: 877 535-7888  | P: 877 535-7888 |
| F: 800 243-3656 | F: 800 283-4050 | F: 877 535-7444  | F: 877 535-7444 |

Copyright © 2017 Pemko Manufacturing Co., an ASSA ABLOY Group company. All rights reserved.  
Reproduction in whole or in part without the express written permission of Pemko Manufacturing Company is prohibited.

DB8\_WEBINS  
Rev 2 - 03.07.17  
Page 1 of 1