

Applies to the following products:


369_V, 369_PK, 369_S, 369_P

Testing/Ratings:

Installation Instructions:

1. Remove pile.
2. Trim to length required.
3. Fasten housing at location desired with screws provided.
4. Reinsert pile in housing.
5. Crimp end to retain.

Tools Required:



Gasketing material for fire doors intended for application to listed steel frames and/or classified steel covered composite type, and hollow metal type fire doors rated up to 3 hours; wood and plastic covered composite type fire doors rated up to 1-1/2 hours; and wood core type fire doors rated up to 20 minutes.

(Thresholds may or may not contain gasketing material).

